

Operating Instructions & Parts Manual



RACING CHAIR

Model
RCOM100




SFA Companies
www.omegalift.com

Read this manual and follow all the Safety Rules and Operating Instructions before using this product.

ASSEMBLY BREAKDOWN

-  M8 * 7 PCS WASHER (9)
-  M8 * 20MM * 3 PCS (10)
-  5/16" * 25MM * 4PCS (11)
-  1/4" * 3/4" BOLT * 6 PCS (12)
-  6MM * 1 PCS (13)
-  SPRING WASHER * 4 PCS (14)




ASSEMBLY INSTRUCTIONS



A

Attach the #2 left handlebar on the #4 seat, secure with screw-driver.



B

Repeat the same process to assemble the #3 right handlebar on the #4 seat.



C

Assemble #7 gas height adjustment with #6 dust cover and then insert into #5 plate.



D

Fix the #5 plate and #4 seat sets using #9 washer and #14 spring washer with #11 bolt.



E

Assemble the #1 back cushion and #4 seat with bolt #10 and washer #9 x 3 pcs by #13 hex key wrench.



F

Fix the #8 chair legs with #4 seat sets.

OPERATING INSTRUCTIONS

SEAT BACK INCLINATION ADJUSTMENT




A

This picture shows the position of the control shaft for seat back angle adjustment. In normal situations, it is located at the level as the picture indicates.

B

Pull the control shaft outward to release the seat back.



C

Change the seat back angle by leaning back to the desired position. Push the control shaft back in to lock the seat back in this position.

D

This picture shows the locked position after seat back angle adjustment.

A	B
C	D



A


This picture shows the position of the seat up/down control shaft. It is the same control shaft that adjusts the seat back angle.

B

Raise the seat by rotating the control shaft clockwise upward without any body weight on the seat. The seat will not raise if there is body weight on it.

C

Lower the seat by rotating the control shaft clockwise upward while seated. Release the control shaft when the desired position is achieved.



A	B
C	

REPLACEMENT PARTS

Individual replacement parts are not available for this product. For questions call or write: SFA Companies 10939 N. Pomona Ave. Kansas City, MO 64153, U.S.A. e-mail: sales@omegalift.com; Tel: (888) 332-6419 Fax: (816) 891-6599; Website: <http://www.omegalift.com>

ONE YEAR LIMITED WARRANTY

For a period of one (1) year from date of purchase, **SFA Companies, Inc.** will repair or replace, at its option, without charge, any of its products which fails due to a defect in material or workmanship under normal usage. This limited warranty is a consumer's exclusive remedy.

Performance of any obligation under this warranty may be obtained by returning the warranted product, freight prepaid, to **SFA Companies, Inc.** Warranty Service Department, 10939 N. Pomona Ave., Kansas City, MO 64153.

Except where such limitations and exclusions are specifically prohibited by applicable law,

(1) THE CONSUMER'S SOLE AND EXCLUSIVE REMEDY SHALL BE THE REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCTS AS DESCRIBED ABOVE.

(2) **SFA Companies, Inc.** SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGE OR LOSS WHATSOEVER.

(3) ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO ONE YEAR, OTHERWISE THE REPAIR, REPLACEMENT OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

(4) ANY MODIFICATION, ALTERATION, ABUSE, UNAUTHORIZED SERVICE OR ORNAMENTAL DESIGN VOIDS THIS WARRANTY AND IS NOT COVERED BY THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.



SFA Companies
10939 N. Pomona Ave. Kansas City, MO 64153
888-332-6419
sales@omegalift.com